



Lighting Control Gear & Accessories

# Mackwell Emergency Module Selection Chart

Q Start T5 Modules

ELG Ref	942--0316A	942--0317A	942--0318A
<b>No. of Cells</b>	<b>5</b>	<b>6</b>	<b>6</b>
<b>Mackwell No</b>	<b>ST504</b>	<b>ST505</b>	<b>ST506</b>
<b>T5</b>			
14W	14	16	
21W	12	15	
24W			10
28W	9*	11*	
35W		10*	
39W			8
49W			7*
54W			5*
<b>T8</b>			
18W			12
36W			10
58W			5*
<b>T5C</b>			
22W			13
40W			13
55W			7*
60W			6*

numbers denote ballast lumen factor (BLF)

\* See Relevant Data Sheet

**Tel: 0870 445 0755 or Fax: 0870 445 0756**

Or call our Lamp and Gear sales hotline on 0870 445 0000